

Fig. 1




Fig. 2

3/7

TRANSMIT UNTIL PUSHBUTTON IS RELEASED




Fig. 3




Fig. 4A







Fig. 4B



PB

0 PUSH BUTTON 1

1 PUSH BUTTON 2

TP

0 VOLATILE COUNTER

1 NON VOLATILE COUNTER


TX1 TX0

0 0 TRANSMITTER 0

0 1 TRANSMITTER 1

1 0 TRANSMITTER 2

1 1 TRANSMITTER 3




AAH NORMAL CODE

A5H PANIC CODE

55H SYNC CODE



XXH UTILITY CODE



= COUNTER VALUE

Fig. 5

7/7



HEADER




Fig. 6